


# Installation Manual

SUZUKI SPLASH 5DR  
SUZ-SPLA-5-A



## COMPONENTS INCLUDED



CL-M02 x 2



CL-M05 x 4



CL-M01 x 2





CL-T01 x 1



# Installation

SUZUKI SPLASH 5DR  
SUZ-SPLA-5-A



# Installation

SUZUKI SPLASH 5DR  
SUZ-SPLA-5-A

