

Installation Manual

HONDA CR-V 5DR
HON-CRV-5-B



COMPONENTS INCLUDED



X2



X2



X2



CL-M02 x 8



CL-M04 x 4



Installation

HONDA CR-V 5DR

HON-CRV-5-B



SIDE SHADE INSTALLATION




Installation

HONDA CR-V 5DR

HON-CRV-5-B



SIDE SHADE INSTALLATION




Installation

HONDA CR-V 5DR

HON-CRV-5-B



SIDE SHADE INSTALLATION



Installation

HONDA CR-V 5DR

HON-CRV-5-B



SIDE SHADE INSTALLATION



X2


Installation

HONDA CR-V 5DR

HON-CRV-5-B



LOAD AREA SHADE INSTALLATION




Installation

HONDA CR-V 5DR

HON-CRV-5-B



LOAD AREA SHADE INSTALLATION



Installation

HONDA CR-V 5DR

HON-CRV-5-B



LOAD AREA SHADE INSTALLATION





X2

Installation

HONDA CR-V 5DR
HON-CRV-5-B



REAR SHADE INSTALLATION






Installation

HONDA CR-V 5DR
HON-CRV-5-B



REAR SHADE INSTALLATION



Installation

HONDA CR-V 5DR

HON-CRV-5-B



REAR SHADE INSTALLATION

