

Installation Manual

TOYOTA RAV4 5DR
TOY-RAV4-5-A




COMPONENTS INCLUDED



SIDE WINDOW X2



LOAD AREA WINDOW X2



TAILGATE WINDOWS X2



CL-M02 x 10



CL-M12 x 2






Installation

TOYOTA RAV4 5DR

TOY-RAV4-5-A



SIDE SHADE INSTALLATION



Installation

TOYOTA RAV4 5DR

TOY-RAV4-5-A



SIDE SHADE INSTALLATION



Installation

TOYOTA RAV4 5DR

TOY-RAV4-5-A



SIDE SHADE INSTALLATION



X2


Installation

TOYOTA RAV4 5DR

TOY-RAV4-5-A



LOAD AREA SHADE INSTALLATION



Installation

TOYOTA RAV4 5DR

TOY-RAV4-5-A



LOAD AREA SHADE INSTALLATION



X2


Installation

TOYOTA RAV4 5DR

TOY-RAV4-5-A



TAILGATE SHADE INSTALLATION



Installation

TOYOTA RAV4 5DR

TOY-RAV4-5-A

TAILGATE SHADE INSTALLATION




Installation

TOYOTA RAV4 5DR

TOY-RAV4-5-A



TAILGATE SHADE INSTALLATION



x2

